




Model : AM4013MZT Dino-Lite Premier

- 10x~50x ,200x
- Polarizer
- Enhanced 1.3 Megapixels
- Aluminum alloy case

200X

 2mm

Metal



Product Description			
Product Number	AM-4013MZT	Magnification	10x, 50X ~ 200X
Warranty Period	1	Pixels	1.3M
Condition	New	Resolution	1280x1024
Packaging	Retail Box	Data Output	USB 2.0
Sensor	Enhanced Color CMOS	Video frame Rate	up to 30 frame-per-second
Illumination	Buit-in 8 white LEDs	Save File format	BMP, JPG, AVI
LED On/Off Function	Yes	Body length	4 inches / 10.2 cm
Body Diameter	1.26 inches / 3.2cm max.	Cable length	6 feet / 180 cm
Total package weight	280g +/- 20g		

Product Applications

The handheld digital microscope AM4013MZT Dino-Lite Pro is a product extended from handheld digital microscope AM413T by adding rotatable polarizer filter. Simply by rotating the polarizer filter, the handheld digital microscope AM4013MZT could amazingly decrease the reflection glare to almost any extent, and could thus help the user see through the surface of fully or partially transparent materials, such as jewelry, skin, glass, and plastic, or see clearly the high reflectivity materials, such as metal or soldering. The handheld digital microscope AM4013MZT could be very useful in some application including PCB, printing, machining, textile, jewelry, or skin care etc.