

Skin Diagnostic® SD 27



An easy to handle device, allows quick analysis of the skin by moisture and sebum measurement. The results are shown on a display and a diode chain. They allow the recommendation of the individual products for each skin type. The sebum measurement can also be performed on hair and scalp. A temperature control button takes the room temperature into account for the moisture measurement.



Technical Data:

Power Supply: battery operated (9 V), optional external power supply (12 V/300 mA); Dimensions: 17 x 20 x 5.5 cm; Weight: 0.5 kg

Measurement principles: oil: photometric, hydration: capacitance

Technical changes may be made without prior notice.